




READ BEFORE PLUGGING the CART INTO an OUTLET!!!!

TO PLUG THE CART INTO POWER:


- 1. Make sure BOTH switches are off!**

Press the bottom of both toggle switches. OFF is on the bottom.



Switch 1


Switch 2



- 2. Plug in BOTH power cords directly into the outlet on the wall located just inside the classroom door or into the black extension cord provided with each cart. *If using the extension cord, plug it into the electrical box located just inside the classroom door.* Do not touch the metal part of the plug. **DO NOT** plug the cords or extension cord into a surge protector.**



YES



NO



- 3. Plug the network cable into an outlet.**

- 4. Turn on BOTH switches by pressing the top (reset) part of each switch.**

